

PROFESSIONAL DIGITAL TWO-WAY RADIO

# MOTOTRBO™ SL2600 PORTABLE RADIO

# **QUICK REFERENCE GUIDE**

| en-US | fr-FR | ru-RU | ar-EG |
|-------|-------|-------|-------|
| cs-CZ | it-IT | ro-RO |       |
| da-DK | hu-HU | fi-Fl |       |
| de-DE | nl-NL | sv-SE |       |
| es-ES | pl-PL | tr-TR |       |
| el-GR | pt-PT | uk-UA |       |



© 2017 Motorola Solutions, Inc. All rights reserved.





MN003121A01-AA

#### Your Quick Reference Guide

This Quick Reference Guide covers the basic operation of the radio. Check with your dealer or system administrator because your radio may have been customized for your specific needs.

For more operational details and information on warnings and safety, refer to the following User Guide:

Limited Keypad Portable

MN003116A01

# Important Safety Information

#### Product Safety and RF Exposure Compliance



Caution: Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

#### ATTENTION!

This radio is restricted to Occupational use only. Before using the radio, read the RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios which contains important operating instructions for safe usage and RF energy awareness and control for Compliance with applicable standards and Regulations.

For a list of Motorola Solutions-approved antennas and other accessories, visit the following website:


http://www.motorolasolutions.com

# **Computer Software Copyrights**

The Motorola Solutions products described in this manual may include copyrighted Motorola Solutions computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs including, but not limited to, the exclusive right to copy or reproduce in any form the copyrighted computer program.

Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this manual may not be copied, reproduced, modified, reverse-engineered, or distributed in any manner without the express written permission of Motorola Solutions. Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive license to use that arises by operation of law in the sale of a product.

#### Radio Controls



- 1 Channel Rocker
- 2 On/Off Button
- 3 LED Indicator4 Push-to-Talk (PTT) Button
- 5 Volume Button
- 6 Programmable Side Button 1
- 7 P1/Left Navigation Button<sup>1</sup>
- 8 Menu/OK Button<sup>1</sup>
- 9 Back/Home Button<sup>1</sup>
- 10P2/Right Navigation Button<sup>1</sup>
- 11 Display
- 12Microphone
- 13USB Connector
- 14 Accessory Connector
- 15Speaker
- 16 Antenna

#### Powering On/Off the Radio

Long press the On/Off button.

These touch screen buttons become visible when the radio is unlocked.

# Adjusting the Volume

Press the Volume Up or Volume Down button.

#### **LED Indicators**

#### Solid Red

Radio is charging.

# Blinking Red

Radio has failed the self-test upon powering up, has Mute mode enabled, has moved out of range if Auto-Range Transponder System is configured, is receiving an emergency transmission, is transmitting in low battery state, or is encountering charging errors.

### Solid Green

Radio is powering up, is transmitting, or is sending a Call Alert or an emergency transmission.

#### Blinking Green

Radio is receiving a call or data, is turned on and idle, or is detecting activity over the air.

#### **Double Blinking Green**

Radio is receiving a privacy-enabled call or data.

#### Solid Yellow

Radio is monitoring a conventional channel.

#### Blinking Yellow

Radio is scanning for activity, is receiving a Call Alert, has Flexible Receive List enabled, or all Capacity Plus-Multi-Site channels are busy.

# **Double Blinking Yellow**

Radio has Auto Roaming enabled, has yet to respond to a Group Call Alert, is actively searching for a new site, is not connected to the repeater while in Capacity Plus, is locked, or all Capacity Plus channels are busy.